

BlueSTAR PnP - Class 2

Quick Start Guide

Thank you for purchasing the BlueSTAR PnP from CoSTAR Technologies. You will soon be using your existing cell phone to communicate hands free using your existing vehicle electronics.

Installation is easy. Simply follow the steps below, and feel free to contact us should you have any difficulties. techsupport@costartech.com

Step 1. Connect the BlueSTAR PnP to the HF850 junction box as shown below. It's best to tie wrap them together so that they do not shake loose.



Step 2. Locate your onstar VIU or VCIM. It can be located beneath the rear seat, behind the glove box, or in the trunk depending on your vehicle.



Step 3. Disconnect the onstar and connect the BlueSTAR PnP as shown. You can tie wrap it in place or use double sided tape either works well. Just keep the BlueSTAR board away from any metal where it might short out. Replace any covers you might have removed to access the onstar module.



Step 4. Pair your phone to the HF850. Follow phone specific instructions to link your phone. The passkey / access code for the HF850 is 0000.



Step 5. Adjust volume if necessary. The HF850 module volume can be adjusted by pressing the RED Emergency button (mute) for three seconds until the LED turns RED. You can then use the White and Blue buttons to adjust the HF850 default volume. You will hear beep tones while doing this. Press the Red key to save this setting.

Step 6. Call a loved one. Press the white key to make a call. Press the Blue to answer a call. More detailed information on advanced features can be found on the website www.costartech.com

