


Communication Interface Module Replacement (with RPO SLT)



Callout	Component Name
<h2>Preliminary Procedure</h2> <ol style="list-style-type: none"> 1. Remove the instrument panel accessory trim plate. Refer to Instrument Panel Accessory Trim Plate Replacement. 2. Remove the HVAC control module. Refer to HVAC Control Module Replacement or HVAC Control Module Replacement. 3. Remove the radio. Refer to Radio Replacement. 	
1	<p>Communication Interface Module</p> <p>Tip</p> <ul style="list-style-type: none"> • Push outward on the 2 tabs to release the communication interface module from the bracket. • Disconnect the electrical connectors. • Reprogram the communication interface module after replacement. Refer to Control Module References. • When replacing the communication interface module be sure to transfer Bluetooth Antenna, if equipped.

