


## Communication Interface Module Replacement



Callout	Component Name
<b>Preliminary Procedure</b>	
Remove the Front Floor Console. Refer to <a href="#">Front Floor Console Replacement</a>	
1	Communication Interface Module Bolt (Qty: 3)  <b>Caution:</b> Refer to <a href="#">Fastener Caution</a> in the Preface section.  <b>Tighten</b> 10 N·m (89 lb in)
2	Communication Interface Module  <b>Procedure</b> <ol style="list-style-type: none"> <li>1. Disconnect the electrical connections.</li> <li>2. If Replacing the Communication Interface Module be sure to transfer Bluetooth Antenna, if equipped.</li> <li>3. Refer to <a href="#">Control Module References</a> for programming and set up procedures.</li> </ol>